

# Firestone

## SPECIALTY PRODUCTS

### **PondGard Installation Detail 8-**

Install a Repair Patch Using a PondGard EPDM Liner Repair Kit

	<p><b><u>Step 1-</u></b> Ensure the liner is dry and free of mud or other contaminants.</p>
	<p><b><u>Step 2-</u></b> Apply the QuickPrime Plus primer by pouring a small amount onto the scrubber pad and applying it to the surface of the PondGard beyond the perimeter of the area to be repaired with a patch.</p>
	<p><b><u>Step 3-</u></b> Test the primer flash-off by touching the primed area with your finger and pushing forward at an angle. The primer should not string as your finger is moved up and away.</p>
	<p><b><u>Step 4-</u></b> Install the QuickSeam patch by peeling away the release paper and placing the patch over the damaged area of the liner.</p>
	<p><b><u>Step 5-</u></b> Roll the patch evenly over the area to be repaired in order to properly mate the patch and liner together.</p> <p><b>If the area cannot be adequately repaired using the two 6" by 6" QuickSeam patches, call Firestone Specialty Products at 800-428-4442 for additional assistance.</b></p>

# Firestone

## SPECIALTY PRODUCTS

---

### **PondGard Installation Detail 8 (continued)-**

Install a Repair Patch Using a PondGard EPDM Liner Repair Kit

#### **This Detail featured these Firestone Specialty Products:**

Item

- EPDM Repair Kit

Part Number(s)

W56RAC0030